

MRX-4X PARTS LIST

Ver. 0703

OP : Optional Parts

H0086	MRX-4X INSTRUCTION MANUAL	H0289	HOUSING FOR 2nd. GEAR
H0087	DECAL MRX-4X	H0290	REAR SOLID AXLE
H0088	DECAL MRX-4X 3pcs.	H0291	REAR DRIVE SHAFT
D0104R	REAR LOWER SUS. SHAFT	H0292	BELT TENSIONER PLATE
H0104L	FRONT LOWER SUS. SHAFT	H0293	BELT TENSIONER SHAFT
J0105U	REAR UPPER SUS. SHAFT	H0295	SPRING FOR 2 SPEED GEAR BOX
D0105R	KING PIN	OP H0296	REAR UNIVERSAL JOINT SET
H0107/1	FRONT STABILIZER BAR	OP H0297	REAR DRIVE SHAFT FOR UNIVERSAL
H0135	FRONT UPPER ARM	H0353	BRAKE CAM
H0136-B	REAR UPPER ARM	H0354	BRAKE PLATE
H0137	FRONT LOWER ARM	OP H0355	BRAKE PAD
H0138	REAR LOWER ARM	H0359	TEFLON BRAKE PAD
H0139-B	FRONT UPRIGHT	H0362	SERVO MOUNT PARTS
H0140-B	REAR UPRIGHT	H0365	SERVO SAVER SHAFT
H0141	FRONT ANTI-ROLL BAR HOLDER	H0366	SERVO SAVER PIPE
H0142	RADIO PLATE MOUNT	H0367	SERVO SAVER SPRING
H0143	MIDDLE SHAFT BRACKET	H0368	GROMMET
H0144	KING PIN BALL CUP	H0369	VENTILATED BRAKE DISK
H0145	ADJUST NUT	H0370	RADIO PLATE
H0146	SUS. ARM SPACER	H0371	TH SERVO MOUNT
OP H0147	REAR UPPER ARM SET	H0372	SERVO SAVER ARM
H0148-B	FRONT BULKHEAD	H0373	RADIO MOUNT PARTS
H0149-B	REAR BULKHEAD	H0374	BATTERY HOLDER FRP
T0154	ECCENTRIC HUB	OP H0375	BATTERY HOLDER CFRP
OP H0158	FRONT UPRIGHT	H0463	FRONT BUMPER
H0161	FRONT UPPER SUS. SHAFT	H0465	FRONT BODY MOUNT
H0163	REAR ANTI-ROLL BAR	H0466-B	REAR BODY MOUNT
H0164	ROLL BAR	H0467	REAR BODY MOUNT CENTERING PLATE
H0180	REAR UPRIGHT BALL	H0468	REAR BOYD MOUNT CENTERING SHAFT
OP H0181	REAR UPRIGHT SPACER	H0469	REAR BODY MOUNT ARM SHAFT
OP H0181A	3mm SPACER 0.5mm	H0470	REAR BODY MOUNT ARM STOPPER
OP H0181B	3mm SPACER 1.0mm	H0471	REAR BODY MOUNT ARM PIN
OP H0181C	3mm SPACER 2.0mm	OP H0473	FRONT BODY MOUNT PLATE CFRP
H0181D	3mm SPACER 3.0mm	H0475	CHASSIS
OP H0185	REAR ADJUSTABLE ANTI-ROLL BAR SET	D0506	REAR DAMPER SHAFT
OP H0186	REAR ADJUSTABLE ANTI-ROLL BAR	D0508	DIAPHRAGM
OP H0187	TITANIUM KING PIN BALL (2 pcs.)	D0509	O-RING SET
OP H0187/1	TITANIUM KING PIN BALL (8 pcs.)	H0510	DAMPER PISTON
H0188	ECCENTRIC HUB	OP H0511	FRONT DAMPER SPRING BLACK ϕ 1.9mm
H0189	UPRIGHT SPACER	H0513	SPRING ADJUSTER
H0190	BRAKE BRACKET	OP H0515	FRONT DAMPER SPRING YELLOW ϕ 1.8mm
H0191	REAR LOWER ARM MOUNT	OP H0516	FRONT DAMPER SPRING BLUE ϕ 2.0mm
D0205	PULLEY HUB	OP H0525	FRONT DAMPER SPRING GRAY ϕ 1.8mm
D0206	INNER DRIVE JOINT	H0526	FRONT DAMPER SPRING WHITE ϕ 1.9mm
OP H0208	FRONT AXLE SHAFT	OP H0529	REAR DAMPER SPRING GRAY ϕ 1.8mm
J0209	MIDDLE SHAFT	H0530	REAR DAMPER SPRING WHITE ϕ 1.9mm
H0222	REAR AXLE SHAFT	OP H0531	REAR DAMPER SPRING PINK ϕ 2.0mm
D0240	BELT S 6mm	OP H0532	REAR DAMPER SPRING RED ϕ 2.0mm
H0240	BELT S 8mm	H0554	DAMPER CAP
H0241	BELT L 6mm	OP H0558	DAMPER PISTON (ϕ 1.2)
OP H0245	BELT S 6mm RUBBER	OP H0559	DAMPER PISTON (ϕ 1.3)
OP H0246	BELT S 9mm RUBBER	H0560	FRONT DAMPER STAY
OP H0247	BELT L 6mm RUBBER	H0561	REAR DAMPER STAY
H0252	FRONT ONE WAY DRIVE AXLE	H0562	DAMPER CASE
OP H0253	FRONT DRIVE SHAFT	H0563	OIL SEAL CAP
H0255	BRAKE PULLEY ADAPTER	OP H0566	FRONT DAMPER STAY
H0256	2 SPEED SHAFT	H0570	DAMPER SET
H0257	2 SPEED ADAPTER	H0571	DAMPER PARTS
H0268	AXLE WASHER	D0601	BEARING (12x21)
OP H0269	TITANIUM MIDDLE SHAFT	H0601	BEARING (12x18)
H0270	FRONT UNIVERSAL JOINT SET	D0602	BEARING (6x13)
H0271	FRONT AXLE SHAFT FOR UNIVERSAL	C0603	CLUTCH BEARING (5x10)
H0272	FRONT DRIVE SHAFT FOR UNIVERSAL	D0603	5mm THRUST BEARING
H0273	JOINT SHAFT FOR UNIVERSAL	H0603	FLANGE BEARING FOR BELT TENSIONER
H0274	ROLLER PIN ϕ 2.5x11.8 (10 pcs.)	C0605	BEARING FOR SERVO SAVER (6x10)
H0275	FRONT WHEEL CHANGE LEVER	H0608	BEARING FOR 2nd. GEAR HOUSING
OP H0277	REAR AXLE SHAFT FOR UNIVERSAL	H0704	ENGINE NUT
H0279	REAR WHEEL CHANGE LEVER	OP H0707	CLUTCH SHOE
H0280	PULLEY SET	OP H0721	PRESSURE PLATE
OP H0281	1st. GEAR 48T	C0723	ENGINE MOUNT FLAT SCREW
H0282	1st. GEAR 49T	OP H0751	FLYWHEEL
OP H0283	1st. GEAR 50T	OP H0752	CENTRIFUGAL SHOE
OP H0284	2nd. GEAR 45T	H0753	SPRING CUP
H0285	2nd. GEAR 46T	H0755	SPRING ADJUST NUT
OP H0286	2nd. GEAR 47T	H0756	BEARING STOPPER
H0287	SHOE FOR 2 SPEED GEAR BOX	OP H0757	1st. GEAR 16T
H0288	HOUSING FOR 1st. GEAR	H0758	1st. GEAR 17T

MRX-4X PARTS LIST

Ver. 0703

OP : Optional Parts

OP	H0759	1st. GEAR 18T		H0852	SNAP RING SET	
OP	H0760	2nd. GEAR 19T		H0853	ROLLER PIN ϕ 3x11.6	
	H0761	2nd. GEAR 20T		H0854	ROLLER PIN SET	
OP	H0762	2nd. GEAR 21T		H0855	BALL LINK ϕ 6mm	
OP	H0764	CLUTCH SPRING HARD		H0856	STABILIZER LINK BALL	
OP	H0765	CLUTCH SHOE (GRAY)		H0857	TURN BUCKLE ROD (22mm)	
OP	H0766	LIGHT WEIGHT CENTRIFUGAL SHOE		H0858	BALL LINK ϕ 6mm (S)	
	H0767	CLUTCH SPRING SUPER HARD		OP	H0862	TITANIUM STEERING ROD
OP	H0769	CLUTCH SHOE (RED)		OP	H0863	TITANIUM TURN BUCKLE ROD (22mm)
	H0770	ENGINE MOUNT		H0864	FUEL TANK CAP	
OP	H0771	CLUTCH SET		H0866	FUEL TANK	
OP	H0772	ONE PIECE ENGINE MOUNT		H0867	PIVOT BALL	
OP	H0773	CLUTCH SHOE (YELLOW)		OP	H0868	TITANIUM SCREW SET A
OP	H0774	CLUTCH SPRING ULTRA HARD		OP	H0869	TITANIUM SCREW SET B
	H0775	CENTRIFUGAL SHOE		C0901	MUFFLER STAY	
	H0776	AL. PRESSURE PLATE		OP	H0901	MANIFOLD SPRING
	H0777	CLUTCH BELL		H0952	WIRE FOR MUFFLER	
	H0778	FLYWHEEL		OP	H1006	REAR SPOILER ADJ. SCREW
	H0779	CLUTCH SHOE (YELLOW)		OP	H1009	BODY STIFFENER
	H0780	CLUTCH SET for MRX-4X		OP	H1010	REAR SPOILER SET
	H0801A	STEERING ROD		OP	H1011	REAR SPOILER
	H0802	ENGINE CONTROL LINKAGE		OP	H1101	FRONT WHEEL (WHITE)
	D0806	ANTENNA PIPE		OP	H1102	REAR WHEEL (WHITE)
	D0807	BODY PIN		P0218	STICKER FLAG & FLAME	
	H0851	E-RING SET				

Other Optional Parts

B0010	"AIR BOOSTER" AIR FILTER SET	B0526/1	3.0mm Hex. WRENCH TIP
B0011	"AIR BOOSTER" AIR FILTER	B0527	2.0mm Ball-Hex. WRENCH
B0103	FUEL FILTER L	B0527/1	2.0mm Ball-Hex. WRENCH TIP
B0104	FUEL FILTER S	B0528	2.5mm Ball-Hex. WRENCH
B0113	AIR FILTER FOR 21ON-ROAD	B0528/1	2.5mm Ball-Hex. WRENCH TIP
B0115	FUEL PUMP 500ml	B0529	PROSPEC TOOL SET
B0116	PRESSURE CHAMBER SET	B0530	2.0mm Hex. WRENCH TIP FOR ELECTRIC DRIVER
B0117	PRESSURE CHAMBER MOUNT	B0531	2.5mm Hex. WRENCH TIP FOR ELECTRIC DRIVER
B0203	QUICK BOOSTER	B0532	PINION GEAR TOOL
B0207	POCKET BOOSTER	B0533	CURVED SCISSORS
B0208	ADAPTER FOR POCKET BOOSTER	B0534	HEIGHT GAUGE R
B0209	BATTERY FOR POCKET BOOSTER	B0663	SG3x12 CAP SCREW
B0213	POWER PACK 1000 (FUTABA)	B0664	SG3x16 CAP SCREW
B0214	POWER PACK 1000 (SANWA)	B0670	SK3x3 SET SCREW
B0220	PRO STARTER R II	B0671	SK3x5 SET SCREW
B0233	BATTERY CODE for R II/B II	B0672	SK3x12 SET SCREW
B0301	LOCK FIRM LIQUID	B0675	SK3x16 SET SCREW
B0303	ENGINE MAINTENANCE OIL	B0681	SK4x5 SET SCREW
B0316	SUPER SILICON #400	B0682	SK4x8 SET SCREW
B0325	SUPER SILICON #500	B0690	SK5x5 SET SCREW
B0326	SUPER SILICON #600	B0712	SN2.6 NYLON NUT (10 pcs.)
B0327	SUPER SILICON #700	B0713	SN3 NYLON NUT (10 pcs.)
B0328	SUPER SILICON #800	B0714	SN4 NYLON NUT (10 pcs.)
B0329	AIR FILTER OIL	B0722	OE-2.5 E-RING
B0330	SUPER JOINT GREASE	B0723	OW3x8x0.5 WASHER
B0332	SUPER SILICON #450	B0724	OE-3 E-RING
B0333	SUPER SILICON #550	B0730	SiG 3x8 B/H SCREW
B0406	BOTH SIDE TAPE	B0731	SiG 3x10 B/H SCREW
B0407	FLAT WASHER 3mm	B0732	SiG 3x12 B/H SCREW
B0408	FLAT WASHER 4mm	B0733	SiG 3x14 B/H SCREW
B0410	COLOR SILICON PIPE PINK	B0734	SiG 3x16 B/H SCREW
B0411	COLOR SILICON PIPE GREEN	B0735	SiG 3x18 B/H SCREW
B0412	COLOR SILICON PIPE YELLOW	B0736	SiG 3x6 B/H SCREW
B0413	COLOR SILICON PIPE GRAY	B0740	SJG 3x8 F/H SCREW
B0424	PORT CAP (L+M)	B0741	SJG 3x10 F/H SCREW
B0506	SNAP RING PLIERS	B0742	SJG 3x6 F/H SCREW
B0509	SETTING DRIVER FOR ENGINE	B0743	SJG 3x12 F/H SCREW
B0510	CAMBER GAUGE	B0746	SJG 4x8 F/H SCREW
B0514	CLUTCH SPRING ADJUSTER TOOL	B0747	SJG 4x10 F/H SCREW
B0519	(+) #2 SCREW DRIVER	B0750	SJG 4x12 F/H SCREW
B0519/1	(+) #2 SCREW DRIVER TIP	B0730T	SiG 3x8T B/H TITANIUM SCREW
B0520	(+) #1 SCREW DRIVER	B0731T	SiG 3x10T B/H TITANIUM SCREW
B0520/1	(+) #1 SCREW DRIVER TIP	B0732T	SiG 3x12T B/H TITANIUM SCREW
B0521	(-) 1.0 SCREW DRIVER	B0733T	SiG 3x14T B/H TITANIUM SCREW
B0521/1	(-) 1.0 SCREW DRIVER TIP	B0734T	SiG 3x16T B/H TITANIUM SCREW
B0522	(-) 0.5 SCREW DRIVER	B0735T	SiG 3x18T B/H TITANIUM SCREW
B0522/1	(-) 0.5 SCREW DRIVER TIP	B0736T	SiG 3x6T B/H TITANIUM SCREW
B0523	1.5mm Hex. WRENCH	B0740T	SJG 3x8T F/H TITANIUM SCREW
B0523/1	1.5mm Hex. WRENCH TIP	B0741T	SJG 3x10T F/H TITANIUM SCREW
B0524	2.0mm Hex. WRENCH	B0742T	SJG 3x6T F/H TITANIUM SCREW
B0524/1	2.0mm Hex. WRENCH TIP	B0743T	SJG 3x12T F/H TITANIUM SCREW
B0525	2.5mm Hex. WRENCH	B0746T	SJG 4x8T F/H TITANIUM SCREW
B0525/1	2.5mm Hex. WRENCH TIP	B0747T	SJG 4x10T F/H TITANIUM SCREW
B0526	3.0mm Hex. WRENCH	B0750T	SJG 4x12T F/H TITANIUM SCREW